# Configuring Digi AnywhereUSB 2 Plus

Version 2022221

# Contents

Configuring Digi AnywhereUSB 2 Plus	2
Connecting to Digi AnywhereUSB 2 Plus Temporary Network Address	6
Configuring settings IP Settings of Digi AnywhereUSB 2 Plus	10
Reverting Computer Network address to original IP address	15
Configuring Settings of Digi AnywhereUSB 2 Plus	18

# Configuring Digi AnywhereUSB 2 Plus

ay kasyala Bin	i I I III ∓ I D:\Digi File Home Share	View				- □ × ~ 0
ABC 3100 ABC 3100 ABC 3100 ABC 3100 ABC 3100 ABC 3100 Sincer Sincer Sincer Sincer Sincer	<ul> <li></li></ul>	B DISK (Dc) → Digi → Name Drivers Protvers Drivers. Driversip Driversip Driversip Driversip installation documentzip	Date modified 6/28/2021 12:09 PM 6/28/2021 10:37 AM 6/28/2021 11:59 AM 6/28/2021 11:51 AM	Type File folder Application Compressed (tipp Compressed (tipp	v         Ø         Search Digit           Sine         13,725 KB         1,819 KB           1,819 KB         4,707 KB	
	4 items					
于 🔎 Туре h	ere to search	0 🛱 🤤	📑 🔒 🛋	Ξ.		へ 管 🚭 🕼 11:12 AM

 Download and install Digi installation file from link <u>https://hub.digi.com/dp/path=/support/asset/anywhereusb-manager-for-64-bit-windows-manager/</u>

	I     Manage     DADigi       File     Home     Share     View       Application Tools	- □ × ~ 0
Ase sto Source of the store Ase store States State	<ul> <li>Carick access</li> <li>Carick access</li> <li>Desktop</li> <li>Devess</li> <li>Devess</li></ul>	
	4 items 1 item selected 13.4 MB	

• "AnywhereUSB Manager - InstallShield Wizard" opens. Click next

Active Breathing Coordinator™ R3.0 Configuring Digi AnywhereUSB 2 Plus Copyright ©2022 Aktina All rights reserved.



• Click on Run as Stand Alone

	File     Home     Share     View     Application Tools	- U ×
8	← → × ↑ 📮 > USB DISK (D; ) > Digi > # AnywhereUSB Manager - InstallShield Wizard X Search Digi	
)	Cuick access     Desktop     Desktop     Downloads     Documents     Pitures     Pitures     Pitures     Pitures	
	<ul> <li>Music</li> <li>Wideos</li> <li>ConeDrive</li> <li>This PC</li> </ul>	
89	USB DISK (Dc) Digit Full Installation Pac Full Installation Pac Cancel	
	Network	
	4 items 1 item selected 13.4 MB	

- After install, click finish
- Start AnwhereUSB Manager

AnywhereUSB I	Manager	>
Enter a unique	Client ID for this user on	this computer
elekta		
	, OK	Cancel
	Jon	Cancel

- "Enter a unique Client ID for this user on this computer
- Type Elekta
- Click Ok



• The Digi device can be seen, but not connected



• It will show unable to connect.

# Connecting to Digi AnywhereUSB 2 Plus Temporary Network Address



The Digi AnywhereUSB 2 Plus has a default address **of 192.168.210.1** The computer's network address must temporarily be changed to configure the device.

• Hit the Windows Key on the Desktop (Bottom Left) or by using your Keyboard.

All Apps Documents Settings	Photos	Web More 🕶 Feedb	ack ···	~ 0
Best match			Version 3.1,21.1	
<ul> <li>Slitheris Network Discovery App</li> </ul>		۲	Summary	
Settings		Slitheris Network Discovery		
Network status	>	App		
Network reset	>			
Ethernet settings	>	📑 Open		
Check network status	>	Run as administrator		
View network computers and devices	>	Open file location     Pin to Start		
View your network properties	>	- Pin to taskbar		
Show available networks	>	Uninstall		
Apps				
Control Panel	>			
Settings	>		i de la companya de la	
Search the web				EE #1

- Type in "Network"
- Left click "Ethernet Settings"

Active Breathing Coordinator™ R3.0 Configuring Digi AnywhereUSB 2 Plus Copyright ©2022 Aktina All rights reserved.



• Left click "Change Adapter Options"

Jun	ings			×	<,
		P Control Panel/All Control Panel Items/Network Connections	-		>
ଜ	Ho	🗧 🕘 🔹 🛧 😰 > Control Panel > All Control Panel Items > Network Connections > 🗸 🗸 Search Network Connections			p
Fi	nd a	File Edit View Advanced Tools			
-		Organize 🕶	100		(
Net	worl	Bluetooth Network Connection			
-		Realtek PCIe GbE Family Controller Qualcomm QCA61x4A 802.11ac			
Ģ	Sta				
P	Eth				
1	Dia				
ogo	VP				
5	Air				
(q))	Mo				
_					
⊕	Pro				
		3 items			000

• Right click "Ethernet" Adapter

Jungs							n x			×
· · · ·	😰 Control Pane	el\All Control Panel Items\Netwo	ork Connections						- 1	) X
G) Hoi	e e • 1	🖻 😨 🗧 Control Panel 🗧 All C	Control Panel Items >	Network Connections 🔹		ٽ ~	Search Network Connection	ins		Q
Find a	File Edit Vie	ew Advanced Tools								
L	Organize 👻	Disable this network device	Diagnose this conne	ection Rename this conne	ction View status of t	this connection	Change settings of this	connection	57 <b>*</b>	
🗇 Star 🔛 Eth 유 Dia 양 VPI	Not : Blue	dooth Network Connection connected tooth Device (Personal Area	Ethernet Wildentin Realtek P	<ul> <li>Disable</li> <li>Status</li> <li>Diagnose</li> <li>Bridge Connections</li> <li>Create Shortcut</li> <li>Delete</li> <li>Rename</li> <li>Dename</li> </ul>	abled alcomm QCA61x	:4A 802.11ac				
sh Air				W Properties						
<sup>(iji)</sup> Mo										
🕀 Pro										
	3 items 1 ite	em selected								()25 P

• Left Click "Properties

Settings		- 0	×
1	Control Panel/All Control Panel Items/Network Connections	-	
Gi Hor	- 🕘 🗢 🛧 🕎 > Control Panel > All Control Panel Items > Network Connections 🔷 💆 🛛 Search Network Connections		,p
Find a Fil	le Edit View Advanced Tools		
	c 🏺 Ethernet Properties 🛛 🗙 ection Rename this connection View status of this connection Change settings of this con	nection	
Network	Networking Wi-Fi		
	Connect using: I network GBE Family Controller all Qualcomm QCA61x4A 802.11ac		
🗇 Stat	🕎 Realtek PCIe GbE Family Controller		
E Eth	Configure		
HE LOW	This connection uses the following items:		
🗇 Dia	Pie and Printer Sharing for Microsoft Networks		
	Cos Packet Scheduler      Cos Packet Sc		
% VP/	Microsoft Network Adapter Multiplexor Protocol     Microsoft LLDP Protocol Driver		
s Ain	Internet Protocol Version 6 (TCP/IPv6)		
5	hand (heipedul) Deviveling		
(q) Mo	Description		
0	Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication		
Pro:	across diverse interconnected networks.		
	OK Cancel		
2	items 1 item selected		835 0

- Select "Internet Protocol Version 4 (TCP/IPv4)"
- You can double Left click or Select "Properties"

Settings	- 0 ×	- 🗆	×
🙀 Cont	rol Panel/All Control Panel Items/Network Connections	-	
ŵ Hor ()	🛧 😰 > Control Panel > All Control Panel Items > Network Connections 🗸 🖑 Search Network Connections		Q
Find a File Ed	it View Advanced Tools		
c 🖗	ection Rename this connection View status of this connection Change settings of this connection	n 📑 🔹	
Network Net	working Wi-Fi		
5 Cc	Internet Protocol Varian & (TCP/ID) // Properties X Controller MID Qualcomm QCA51x4A 802.11ac		
🖨 Stat			
E7 Fab.	Genera		
Har CUN TH	You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the average internet them and them and the setting of the setting o		
n Dia	for the appropriate the seconds.		
1	Obtain an IP address automatically		
% VPI	D withown 192 168 210		
1	Schoet mode: 255, 255, 255, 0		
r∰> Air;	Default costeway: 192, 169, J, 1		
(0) Mo			
1. 110	Obtain DNS server address automatically     Obtain DNS server addresses:		
Pro:	Preferred DNS server:		
	Alternate DNS server:		
	Validate settings upon exit Advanced		
3 items			800

- Enter the fallow numbers in there respected filled Please Ignore the "Default gateway"
- IP Address: 192.168.210.10 Hit enter and Subnet Mask should auto fill if not already there.
- Subnet Mask: 255.255.255.0

Settings	
👰 Co	introl Panel/All Control Panel Items/Network Connections 🗆
Gi Hor	😑 🕆 😰 > Control Panel > All Control Panel Items > Network Connections 🗸 🖏
Find a File	Edit View Advanced Tools
C I	🛿 Ethemet Properties 🛛 🕹 ection Rename this connection View status of this connection Change settings of this connection 🕷 💌 🔳
Network	Networking Wi-Fi
	Controller Controller Michael Controller
🕀 Stat	Internet Protocol Version 4 (ILP/IPVA) Properties
-	General
P⊒ Eth	The You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network assimiliatator
🗇 Dia	for the appropriate IP settings.
	G Obtain an Draddress automatically.
980 VPI	Buse the tolowing IP appress
	Subnetmask: 255.255.25.0
¶> Airp	Cefault gateway: 192 . 168 . 210 .
(iji) Mo	Chitain DNS cenuer address automatically
	Use the following DNS server addresses:
Pro:	Preferred DNS server:
	Alternate DNS server:
	Validate settings upon exit
2.24	Advanced
3 iten	ns Dy Caral

• Left Click "OK" Confirm Setting

Se	ttings						- 1	1 ×		n x	- E	í X	¢
		🕎 o	Control Panel/All Control Panel Items/Network Connections								-		×
ផ	3 Hor	æ	$iegginarrow \uparrow 🕎 > Control Panel > All Control Panel Items >$	Network	Connections			~	Ö	Search Network Connections			p
Г	Find a	File	Edit View Advanced Tools	-									
		¢	Ethernet Properties ×	ection	Rename this	connection	View status	of this con	nection	Change settings of this connection	10	. 💷	0
N	etwork	1	Networking			870	Wi-Fi						
		3	Connect using:	d networ e GbE Fai	k mily Controller	2	Disabled Qualcomm QC	461x4A 802.	11ac				
₿	Stat		🚽 Reatek PCIe GbE Family Controller										
			Configure										
, Ta	- Ethe		This connection uses the following items:										
6	Dia		Guent for Microsoft Networks      Generating for Microsoft Networks										
			Gos Packet Scheduler     Johannet Protocol Version & (TCP (IP)(4)										
%	° VPI		C Antonio State St										
			Internet Protocol Version 6 (TCP/IPv6)										
ÿ	> Air		< >										
(q:	) Mo		Install Uninstal Properties										
8			Allows your computer to access resources on a Microsoft										
€	Pro:		network.										
			Close Cancel										
		_		1									8 10
		3 ite	ems 1 item selected										814 M

- Close the Ethernet Properties Tab and Adapter window for now.
- Left Click Microsoft Edge or any web browser.

### Configuring settings IP Settings of Digi AnywhereUSB 2 Plus

$\leftrightarrow$ $\rightarrow$ O $\hat{\omega}$ $\odot$ 192.168.210.1/	x				
	м	75	h	Ē	
You're not connected         And the web just isn't the same without you.         Let's get you back online         • Check that your network cables are plugged in.         • Make sure you're not in airplane mode.         • See if your wireless switch is turned on.         • Restart your router.         Help me fix it					

- Type the fallowing in the Address Bar "192.168.210.1"
- Hit enter

Active Breathing Coordinator™ R3.0 Configuring Digi AnywhereUSB 2 Plus Copyright ©2022 Aktina All rights reserved.



- You should see the fallow Message
- Left click "Details"



• Left click "Go to the webpage" On the bottom in Red Lettering

🖻 🖷 🖸 You're not connected 📄 Digi AnywhereU	58 2 Ph × + ~			<del></del>	٥	×
← → Ů ⋒ ▲ Certificate error https://192.10	58.210.1/	Ô.	☆	1 ₪	Ê	
Digi AnywhereUSB 2 Plus			<b>b</b> Digi	Remote	e Manag	jer®
	Login to device AW02-007018					
	Device Login Username admin Password					
	••••••					
	Caps Lock is on					
https://192.168.210.1/						
P Type here to search	o # 📴 💻 🕯 🛥 🍱 🖊		` '® ∉	ta d≫) 6/	:46 AM 28/2021	5

- Type your Username and Password for your device.
- Username is "admin"
- Password is located on the back of your Digi Device. (uppercase)
- Left Click Login.

· → Ŭ ⋒ <u>A</u> Certificate erro	https://192.168.210.1/			
DIGI / AnywhereUSB 2 Plus			🕐 Dashboard 📲 Status 🔗 🔅	System × 🛛 admin
etwork Activity thernet: ETH eceived 67.16 kB ent 80.41 kB	Digi Remote Manager* Status X Disconnected Down Time 3 minutes Device Id 0000000- 0000000- 0004F3FF-FF232560 Go To Digi Remote Manager*	Dashboard Device Uptime Firmware Version Local Time RAM Usage	Configuration Device Configuration Digi Remote Manager* AnywhereUSB Configuration Configuration Maintenance	Administration Terminal File System Logs Support Report • Find Me Firmware Update Reboot
etwork Interfaces  ETH ¥ Pending  v//192.168.210.1/config/	Modems No configured modems available.	AnywhereUSB Se Status USB Devices Groups	ervice Running O devices O groups in use	

- On the Home Page on the upper right. Left click "System" with the Gear icon
- Under Configuration Colum, Left Click "Device Configuration".

E +5 ☐ You're not connected       ☐ Digi AnywhereUSB 2 Pk ×     +		-	٥	×
← → Ŭ ඣ Certificate error https://192.168.210.1/config/	□ ☆	⋬	L &	
Comguation				_
EX	PAND ALL	P		
- Central management	-			
* Network	-			
▼ Interfaces	-			
- ETH	-			
- Loopback	-			
- Default IP 步	-			
- Default Link-local IP	-			
Add Interface	+			
- Virtual LAN	-			
- Bridges	-			
🕂 🔎 Type here to search O 🛱 😢 🧮 🏦 😭 🌃 🚩	~ 19	<b>€</b> ↔))	11:46 AM 6/28/2021	5

- Left Click "Network" Then addition Option will drop down.
- Left click "Interfaces"
- Left Click "Default IP"

🖻 🖅 🖾 You're not cr	connected	$\Box$ Digi AnywhereUSB 2 Plt $\times$	+ ~					٥	×
$\leftrightarrow$ O $\Leftrightarrow$	▲ Certificate	error https://192.168.210.1/cor	fig/			□ ☆	在 几	ß	
	+ ETH								4
	+ Loopback					-			
	Y Default IP					÷			
	Enable					-			
	Interface type		Static IP address		8.00	-			
	Zone		Setup		1.				
	Metric		10			-			
	Weight		10			-			
	Management p	riority	0			-			
	мти		1500			-			
	Device		Ethernet: ETH		-	-			
	Address		192.168.210.1/24	Default gateway	*	-			
	Default gatewa	iy.				-			
	+ DNS server	75				-			
🛨 🔎 Type here to	o search	0 1	: 😑 🛤 🔒	🖬 🖪 📕		~ 12		6 AM 3/2021	5

- In the Address Row where you see "192.168.210.1/24"
- Change the fallowing values to match below
- 192.168.1.49/24

🔁 🕫 🖂 You're no	ot connected	$\Box$ Digi AnywhereUSB 2 Plt $ imes$ +	¥			- ø ×
$\leftrightarrow$ $\circ$ $\circ$	▲ Certifica	te error https://192.168.210.1/config/			□ ☆	\$ \$ \$ \$
DIGI	us			🔀 Dashboard	Status 🔗 🌣 System	V 🛛 O admin
			Configuration			
					EXPAND ALL	
	- Central manag	ement			-	
	• Network				-	
	• Interfaces				-	
	+ ETH				-	
	- Loopback				-	
	▼ Default IP				-	
	Enable				200	
	Interface type	(	Static IP address		-	
	Zone		Setup		-	
ー ア Type here	e to search	0 #	😑 🛤 🔒 🖼		~ 恒	€ 4») 11:46 AM 6/28/2021 ₹

- Scroll up and Left Click "Apply".
- Refresh your web browser and you should have lost access to the site.
- We shall return to the Ethernet Settings Window Left open.

#### 🖹 🖅 Can't reach this page 🛛 🗎 Can't reach this page 🛛 🗧 - o × 0 192 168 210 1 $\leftarrow \rightarrow$ 0 ŵ Settings X ରି Home Ethernet Find a setting Unidentified network Network & Internet Status Related settings 😨 Ethernet Change adapter options Change advanced sharing opti Dial-up Network and Sharing Center VPN Windows Firewall Airplane mode Get help ((j)) Mobile hotspot Cive feedbac Proxv ー ア Type here to search 0 🗄 😫 🔚 🏦 🖬 🗾 🕷 🚩 🌣 ^ 🛥 🤀 ⊲» [

#### Reverting Computer Network address to original IP address

- If you closed it.
- Left Click the Windows Key on the bottom left of the screen or hit the Windows Key on your keyboard.
- Type the fallowing "Network" into the search bar. If you do not see one simply start typing after press the Windows Key. and Left Click "Ethernet Settings"
- Left Click "Change Adapter option"



• Right click "Ethernet" Adapter

Active Breathing Coordinator™ R3.0 Configuring Digi AnywhereUSB 2 Plus Copyright ©2022 Aktina All rights reserved.

Jett	ngs							^		n x		- 11	×	
		😰 Control Pan	el\All Control Panel Items\Netw	ork Connections								-		×
ගි	Hoi	e 9 ° 1	🕆 😰 > Control Panel > All (	Control Panel Items >	Network	Connections >		~	ō	Search Network Conne	ctions			P
F	nd a	File Edit Vie	ew Advanced Tools											
-		Organize 👻	Disable this network device	Diagnose this con	nection	Rename this connecti	on View status of	this conn	ection	Change settings of th	his connection	100		8
Ne	twork	Blue blue	tooth Network Connection	Ethernet		1000	Wi-Fi							
æ	~	Silver	connected tooth Device (Personal Area	Realtek P	Disa Stat	sble tur	alcomm QCA61	x4A 802.1	1ac					
¢	Stat				Diag	gnose								
臣	Eth				💡 Brid	Ige Connections								
0					Crea	ate Shortcut								
ar.	Dia				👽 Dele	ete Jame								
080	VPI				🐶 Proj	perties	-							
s.					-									
5	Air													
(q))	Мо													
~														
₽	Pro													
		3 items 1 ite	em selected										1	(EE

• Left Click "Properties

Settings	- 0 × 0 ×	- 0	$\times$	
1	Control Panel/All Control Panel Items/Network Connections	100		×
G Hor	😑 🗢 🛧 😰 > Control Panel -> All Control Panel Items -> Network Connections -> 🗸 🖏 Search Network Connections			p
Find a Fi	e Edit View Advanced Tools			
	📱 Ethernet Properties 🗙 ection Rename this connection View status of this connection Change settings of this connect	ion 📳 - 🔻		0
Network	Networking Wi-Fi			
	Connect using: Disabled Disabled Qualcomm QCA61x4A 802.11ac			
🖨 Stat	🛒 Reatek PCIe GbE Family Controller			
FT Fth	Configure			
inger Land	This connection uses the following tems:			
🗇 Dia	Pie and Printer Sharing for Microsoft Networks			
	Los Packet Scheduler      Los Packet Scheduler      Los Packet Scheduler      Los Packet Scheduler			
% VPr	Microsoft Network Adapter Multiplexor Protocol     Microsoft LLDP Protocol Driver			
r∯> Ain	Internet Protocol Version 6 (TCP/IPv6)			
	Instal Upperfail Provides			
(i) Mo	Description			
A Bros	Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication			
₩ P10.	across diverse interconnected networks.			
	UK			
3	items 1 item selected		833	E ()

- Select "Internet Protocol Version 4 (TCP/IPv4)"
- You can double Left click or Select "Properties"

	Setting	s						- 1	1 ×		n v l		- []	×	
		😰 c	ontrol Pane	el\All Control Pane	l items\Netw	ork Connection							100		×
	ŵ	Hor	9 - 1	🖉 » Control I	Panel > All	Control Panel Ite	ms → Ni	etwork Connections	¥	Ö	Search Network Conn	iections			p
	Fine	La File	Edit Vie	w Advanced	Tools		P Etho	unat Statue themet Bronecties	×	1					
		Org	anize 🔻	Disable this net	work device	Diagnose th	Note	underna .		nection	n Change settings of	this connection	100 ×		2
	Netw	ork 💦	Blue	tooth Network Co	nnection	Ethe	Car	working	1						
			Blue	connected tooth Device (Pers	onal Area	Net Rea		Internet Protocol Version 4 (TCP/IPv4) Properties			×				
	9	ita1	•					General							
Ι.	_						Th	You can get IP settings assigned automatically if yo	r network	supports	e				
	Έ. I	the					6	this capability. Otherwise, you need to ask your ne for the appropriate IP settings.	work admin	istrator					
	<u>م</u>	Dial					1	O Obtain an IP address automatically							
							8	Use the following IP address:							
	w	/PI					8	IP address: 192 . 168	. 1 . 10						
	_						8	Subnet mask: 255 , 255	. 255 . 0						
	*	Airp						Default gateway: 192 . 168	. 1 . 1		т				
	(i) (i)	10					-	Obtain DNS server address automatically							
	Six i	10						Use the following DNS server addresses							
	⊕ I	ro					14	Preferred DNS server: .							
								Alternate DNS server:		-778	_				
								Validate settings upon exit	Adv	anced	a 1				
											-			0-	

- Return the existing values in their respected fills Please Ignore the "Default gateway"
- IP Address: **192.168.1.10** Hit enter and Subnet Mask should auto fill if not already there.
- Subnet Mask: 255.255.255.0

Settings		×	n x l		×	
Control Panel All Control Panel Items Network Connection	5			100		×
(i) Hor ← → ↑ 1 Control Panel > All Control Panel I	ems > Network Connections	y Ö	Search Network Connections			p
Find a File Edit View Advanced Tools	Ethemat Statue	×				
Organize - Disable this network device Diagnose t	h ( Networking	nection	Change settings of this connection	10 m v		0
Image: State     Image: State       Image: State	Construct Protocol Version 4 (TCP/IP-4) Properties General The You can get IP settings assigned automatically if your networ this capability. Otherwise, you need to ask your network and for the appropriet IP settings. Obtain an IP address: IP add	rk supports ministrator	×			
3 items 1 item selected	Valdate settings upon exit	dvanced			000	85 1

- Left Click "OK"
- Then proceed to close all Tabs and Windows relating Network Settings.

# Configuring Settings of Digi AnywhereUSB 2 Plus

🖻 🕫 🗖 Start	× + ×							٥	×
$\leftrightarrow$ $\rightarrow$ X $\textcircled{a}$	9 192.168.210.1/	I					\$≡ /	ß	
・ ア Type here to sea	irch	o # 😑 🗮	🔒 🖬 🛛	<b>16 🕅 1</b>	EH.	~ 1	■	:14 AM 29/2021	3

• Open Web Browser and type **192.168.1.49** (The address of the Digi Device)



• Click on Details

Active Breathing Coordinator™ R3.0 Configuring Digi AnywhereUSB 2 Plus Copyright ©2022 Aktina All rights reserved.



• Click on Go to the webpage (not recommended)

🖻 🖷 🗖 Digi AnywhereUSB 2 Pli X 🕂 🗸		- 0 ×
$\leftarrow$ $\rightarrow$ $\circlearrowright$ $ເall$ $\land$ Certificate error https://192.1	68.210.1/	□☆ ☆ ℓ &
Digi AnywhereUSB 2 Plus Industrial		Ligi Remote Manager®
	Login to device AW02-007035	
	Device Login Username admin Password	
	Caps Lock is on	
https://192.168.210.1/ ∰ ∕P Type here to search	o 🖽 😋 📷 💼 🖬 🖬 🗰	へ ‱ ஞ (4) 11:15 AM <b>号</b> ))

- For Username type admin
- For Password type the keycode on the back of the Digi device (Upper case)

$\leftarrow \rightarrow \bigcirc$ $\bigtriangleup$ $\bigtriangleup$ Certificate error	https://192.168.210.1/			
DIGI.		( Dashboard	Dashboard     Dashboard     Configuration	System × Q admin
Network Activity Ethernet: ETH Received 254.56 kB Sent 66.33 kB	Digi Remote Manager* Status X Disconnected Downtime 2 mins, 5 secs Device Id 00000000- 0004F3FF-FF232577 Go To Digi Remote Manager*	Device Uptime Firmware Version Local Time CPU Usage RAM Usage	Configuration     Device Configuration     Digit Remote Manager*     AnywhereUSB Configuration     Configuration Maintenance	Terminal File System Logs Support Report • Find Me Firmware Update Reboot
Network Interfaces  TH Pending  https://192.168.210.1/swusb//view=config	Modems No configured modems available.	AnywhereUSB Se Status USB Devices Groups	rvice Running 2 devices 0 groups in use 0 correctioned	

• Click System - AnywhereUSB Configuration

🖻 🖅 🗖 Digi AnywhereUS	82Pli × + ∨			-	٥	×
$\leftarrow$ $\rightarrow$ $\circlearrowright$ $\land$	Certificate error https://192.168.210.1/awusb/?view=config		☆	\$≡ ℓ	L B	
	AnywhereUSB Configuration		APPL			1
	▼ Group Settings					
	Group Port Assignments					
	Description 1 2					
	1 Group 1					
	2 Group 2					
	Unassigned					
		1				
	▼ Client Settings					
	Select a client to configure:					
	Edit					
	Remove					
	Settings for Client					
	Client ID: elekta Add Client					
	Certificate: Unavailable					
	Description					
	Description:					
	Group Access: 1 ×					
				n 11	:15 AM	
Iype here to sea			~ 10 (	8 <sup>(10)</sup> 6/.	29/2021	-(3)

- Type elekta For client ID
- Click Group access 1 and 2
- Under Group settings assign ports 1 and 2 to group 1

0 🏠	Certificate error https://192.168.210.1/a	wusb/?view=config		□ ☆	\$ ₽	Ê
		AnywhereUSB Config	uration	APP	w.	
	▼ Group Settings					
	Group Description	Port Assignments 1 2				
	1 Group I					
	2 Group 2 Unassigned					
	2007 (1990 MCC 1990)		×			
	* Client Settings	This site says				
	Select a client to configure:	Save changes to client ""?				
		ок 😓	Cancel			
		Renove				
	Client ID: elekta	Add Client				
	Certificate: Unavailable					
	Description:					
	Group Access: 1-2					

• Appy and save changes

Resyster			
ABOC ABOC ADDRESS	AnywhereUSB® Manager File Configure Help      AnywhereUSB® (Dus Hulds     AnywhereUSB® (Dusha)     AnywhereU	- C X AnywhereUSB Manager Version 3.1.21.1 Connection Summary 1 Active (secure)	
Suffrance Needraw	< Ready	> 1 Hub active, 1 total	
Type here to search	o # e m 🔒	<u> • • •</u>	^ 등 ಈ (0) <sup>11:17 AM</sup> ♥

- Open AnwhereUSB Manager
- You should now see Group 1 under your Digi device

Recycle Bin			
	AnywhereUSB & Manager File Configure Help AW02-007335 AW02-00735 Connect to Group 1 Connect to Group Assign LB2st Name Power Cycle Device	- C X Vendor: MOON Product: AND Product: D: 0x13EE Product: D: 0x0001 Adress: 1102 Serial: @LAB Status: No one is using this device	
Anyoniteree Mininger Leunedi USB Stater			
Silicas Vielicas	с [1На [1]	s ub active, 1 total	
チーア Type here to search	o # e 🛤 🏦 🖬		へ 毎 (最 か)) 11:17AM 見

- Right click Device
- Connect to Group