

# DisplayLink USB Display Adapter

## Installation Guide

---

This guide contains installation instructions for the following operating systems:

1. [Windows](#)

# DisplayLink USB Display Adapter

## Installation for Windows

### Install Guide

#### To install the driver:

1. Right-click the zip folder that you downloaded, select **Extract All**, and follow the on-screen instructions.
2. In the list of extracted files, right-click the **Setup.exe** file and select **Run as Administrator**.

**Note:** If the **Run as Administrator** option is not available, you might be attempting to run the installer from within the zipped file. Please extract the files using the instructions in Step 1.

3. Follow the on-screen prompts to install the device drivers and restart the computer when prompted.
4. Once Windows has restarted, connect the USB video adapter to your computer.
5. Your computer will automatically complete the driver installation and your device should be ready to use.

**Note:** Installation may take several seconds to complete. During the installation your display might flicker; this is normal. Once the installation has completed you will see your Windows desktop extended to the additional monitor.

**Note:** If you are trying to install the driver for the IPUSB2VGA or IPUSB2HD2, please click here: [https://www.startech.com/faq/ipusb2vga\\_ipusb2hd2\\_install\\_windows\\_v78](https://www.startech.com/faq/ipusb2vga_ipusb2hd2_install_windows_v78)